

INSTALLING THE SWAN NECK SPOUT GW-261 DRINKING FOUNTAIN

PTFE Thread Sealant
should be used to
prevent leaks

Apply a small amount of
Silicone under the white
plastic washer

- White Base Washer
- SS Back Washer
- Backnut
- Brass Extension
- 3/8" Step up Fitting
- 15mm
Compression
Fitting

CHECK FOR LEAKS!

