


Battery Cover Opening Instructions



Without the use of a Dispenser Key



To open the battery cover, insert a 4mm slotted screwdriver into either right-hand slot at the 3 o'clock position. Press down and lift the hinged cover open