

Flow Saver Solenoid Connector Plug Wiring Instructions



Remove Screw



Lever open plug face  
with Small Screwdriver


Valve Plug Assembly



Terminal 1 = Brown  
Terminal 2 = Blue  
Centre Earth - NOT USED



Thread the supplied 2 core cable  
through the valve plug casing



Push the connector  
onto the valve and  
make the connections:  
Terminal 1 = Brown  
Terminal 2 = Blue

